A line drawing of a garment steamer. It features a top handle with a control knob, two vertical support poles, and a base unit with a water tank and a steam nozzle. The drawing is positioned on the left side of the page.

# SALAV

## USER MANUAL

Please read all instructions  
carefully before using  
this product.

**Garment Steamer**  
Model: GS68-BJ



[www.salavusa.com](http://www.salavusa.com)

## Dear Valued Customer

Thank you for purchasing this SALAV product. Please read this manual prior to using your SALAV appliance. For more product information, FAQ and customer support please visit our website at [www.salavusa.com](http://www.salavusa.com).


### Important Safety Instructions:

1. The voltage of your electrical source must correspond to that of the appliance (110V-120V/60Hz). Connecting to the incorrect voltage may cause unreparable damage to the appliance and will invalidate the warranty.
2. Do not share the power supply with other high-powered electric appliances.
3. To reduce the risk of electric shock, do not immerse the appliance, plug, or power cord in water or other liquids.
4. Do not leave this appliance unattached while it is in operation.
5. Fill water to "MAX" level before using and observe the water level during use.
6. Do not lay hose on the ground. Do not wind hose. Do not operate the appliance if the power cord is damaged.
7. Always keep the hose and nozzle elevated above the water tank. Never insert any object into any opening or hose.
8. Do not cut or attempt to extend the steaming hose or power cord.
9. Do not place the nozzle directly on any surface or appliance power cord while it is hot or plugged in.
10. Be cautious about steam spraying out from the nozzle. Do not direct steam at people or animals, or use steamer on garments while they are being worn.
11. Steam only in a vertical motion. Never use steamer in horizontal position or tilt backwards, doing so may result in hot water discharge.
12. Turn off, unplug and allow the appliance to cool completely for at least 30 minutes prior to draining the water tank and water reservoir and storing.
13. Always turn off and unplug unit before refilling, draining, cleaning, moving, or when not in use.
14. For indoor use only.
15. Keep the appliance away from flammable materials and chemicals.
16. Do not fill the water tank with hot water or corrosive cleaning agents which could cause damage. Distilled or filtered water is strongly recommended.
17. Only use SALAV accessories on your SALAV appliance. The use of accessory attachments other than those provided by SALAV may result in fire, electric shock or irreversible damage to the appliance.
18. This appliance is not intended for use by children or near children and other persons whose physical, sensory or mental capabilities or lack of experience and knowledge prevents them from using the appliance safely without supervision or instruction by a responsible person to ensure that they can use the appliance safely.
19. Do not use an extension cord. If an extension cord is used, the power cord must be more than 15A electrical current. Using any power cord under 15A may cause the electric wire to overheat. Do not share the extension cord with other electrical appliances.

## COMPONENTS



Multifunctional Hanger



Steam Hose



Water Tank with Cap



Telescopic Poles



Steam Nozzle



Drain Plug



Fabric Brush




Pants Press



2 Clips



Mini Ironing Paddle




## PRODUCT SPECIFICATION

Model	GS68-BJ
Water Tank Capacity	1.6L
Steam Output Time	45 seconds
Input Voltage	110V-120V/60Hz
Output Power	1260-1500W

# INSTALLATION INSTRUCTIONS


## STEP 1

Install the Telescopic Pole (The side with triggers) into the Multifunctional Hanger, insert the other side into the main body, and lock in place.




## STEP 2

Extend the Telescopic Poles to desired height and lock in place.




## STEP 3

Install the Steam Hose and tighten the Hose Connector.



## STEP 4


Hang steamer nozzle handle to the Multifunctional Hanger hook.



# INSTRUCTIONS FOR USE


## STEP 1

Fill in the Water Tank and replace & tighten its cap.



## STEP 2

Plug in & Turn on.




## STEP 3

45-80 seconds steam ready time depending on steam setting.



## STEP 4


Ready for garment steaming.



## MAINTENANCE AND CLEANING

### STEP 1


Turn off the unit and unplug it. Wait for at least 30mins until the unit cools down completely.



### REMOVING MINERAL BUILD-UP


#### STEP 1

Turn off and unplug the unit and cool for at least 30mins. Remove water tank. Mix water & vinegar solution and pour into water reservoir.



### STEP 2


Disassembly: Press the Telescopic Poles Locks at the bottom of the base to unlock the poles with both hands, pull out the poles. Unscrew the Drain Plug to empty the water reservoir.





Attention: Screw the Drain Plug back into place after the water reservoir is emptied. Make sure the Drain Plug is tightly screwed each time before use.

#### STEP 2





Wait for 40mins, unscrew the Drain Plug and drain the water reservoir. Pour clean water into reservoir and let it drain. After the reservoir is empty, replace and tighten the Drain Plug.






## ACCESSORIES ASSEMBLY AND USE







## ACCESSORIES ASSEMBLY AND USE



## STEAMING INSTRUCTION



# TROUBLE SHOOTING

PROBLEM	REASONS	SOLUTION
<p>Unit fails to steam. Indicating lamp does not illuminate.</p> 	<p>The unit is not plugged in</p>  <p>Household power system problem/ fuse is blown.</p> 	<p>Plug into electrical outlet</p>   <p>Reset the circuit outlet or contact a qualified electrician for help.</p>
<p>Unit fails to steam. Indicating lamp illuminates.</p> 	<p>Mineral build-up in the unit</p>  <p>Water tank is empty</p> 	<p>Follow the removal mineral build-up procedure.</p>  <p>50% Vinegar + 50% Water</p>  <p>Refill the water tank.</p>
<p>Noise in Steam Hose. Steam Hose stops spraying steam.</p>  <p>PO PO PO</p>	<p>Water drops gather in the Steam Hose.</p>  <p>PO</p>	 <p>»»</p> <p>Straighten the Steam Hose.</p>
<p>Steam is intermittent</p> 	<p>Mineral build-up in Water Tank.</p> 	<p>Follow the removal mineral build-up procedure.</p>  <p>50% Vinegar + 50% Water</p>

Visit our website to find product tips, customer support and learn about  
SALAV patented steam technology.  
[www.salavusa.com](http://www.salavusa.com)

