

A line drawing of a garment steamer. It features a base with a water tank, a vertical tube with a flexible section, and a hand-held nozzle with two side arms. The drawing is positioned on the left side of the page, extending from the top to the bottom.

SALAV

# USER MANUAL

Please read all instructions  
carefully before using  
this product.

## Garment Steamer

Model: GS14-DJ



[www.salavusa.com](http://www.salavusa.com)

## Dear Valued Customer

Thank you for purchasing this SALAV product. Please read this manual prior to using your SALAV appliance. For more product information, FAQ and customer support please visit our website at [www.salavusa.com](http://www.salavusa.com).


### Important Safety Instructions:

1. The voltage of your electrical source must correspond to that of the appliance (110V-120V/60Hz). Connecting to the incorrect voltage may cause unreparable damage to the appliance and will invalidate the warranty.
2. Do not share the power supply with other high-powered electric appliances.
3. To reduce the risk of electric shock, do not immerse the appliance, plug, or power cord in water or other liquids.
4. Do not leave this appliance unattached while it is in operation.
5. Fill in water before using and observe the water level during use.
6. Do not lay hose on the ground. Do not wind hose. Do not operate the appliance if the power cord is damaged.
7. Always keep the hose and nozzle elevated above the water tank. Never insert any object into any opening or hose.
8. Do not cut or attempt to extend the steaming hose or power cord.
9. Do not place the nozzle directly on any surface or appliance power cord while it is hot or plugged in.
10. Be cautious about steam spraying out from the nozzle. Do not direct steam at people or animals, or use steamer on garments while they are being worn.
11. Steam only in a vertical motion. Never use steamer in horizontal position or tilt backwards, doing so may result in hot water discharge.
12. Turn off, unplug and allow the appliance to cool completely for at least 30 minutes prior to draining the water tank and water reservoir and storing.
13. Always turn off and unplug unit before refilling, draining, cleaning, moving, or when not in use.
14. For indoor use only.
15. Keep the appliance away from flammable materials and chemicals.
16. Do not fill the water tank with hot water or corrosive cleaning agents which could cause damage. Distilled or filtered water is strongly recommended.
17. Only use SALAV accessories on your SALAV appliance. The use of accessory attachments other than those provided by SALAV may result in fire, electric shock or irreversible damage to the appliance.
18. This appliance is not intended for use by children or near children and other persons whose physical, sensory or mental capabilities or lack of experience and knowledge prevents them from using the appliance safely without supervision or instruction by a responsible person to ensure that they can use the appliance safely.
19. Do not use an extension cord. If an extension cord is used, the power cord must be more than 15A electrical current. Using any power cord under 15A may cause the electric wire to overheat. Do not share the extension cord with other electrical appliances.

## COMPONENTS




360° Swivel  
Folding Hanger



Steam Hose &  
Hose Connector



Water Tank  
with Cap




Pole Connector  
&  
Telescopic  
Pole



Fabric Brush



Pants Press



Drain Plug



Steam Nozzle




## PRODUCT SPECIFICATION

|                     |                 |
|---------------------|-----------------|
| Model               | GS14-DJ         |
| Water Tank Capacity | 1.3L            |
| Steam Output Time   | 45 seconds      |
| Input Voltage       | 110 - 120V~60Hz |
| Output Power        | 1260 - 1500W    |

# SETTING UP YOUR GARMENT STEAMER


## STEP 1

Loosen the Pole Connector and insert Telescopic Pole. Tighten Pole Connector to secure Telescopic Pole in Place.




## STEP 2

Attach the Folding Hanger to the top of the Telescopic Pole. Extend the Telescopic Pole to desired height and lock in place.




## STEP 3

Install the Steam Hose and tighten the Hose Connector.



## STEP 4


Fully extend Hanger Arms and hang the Steam Nozzle.



# INSTRUCTIONS FOR USE

## STEP 1

Remove the cap. Fill the Water Tank. Replace & tighten the Cap.




## STEP 2

Plug in & Turn on.



## STEP 3

Heats up in 45s



## STEP 4


Ready for steaming.



## MAINTENANCE AND CLEANING


### STEP 1

Turn off the unit and unplug it. Wait for at least 30mins until the unit cools down completely.



### STEP 2


Unscrew the Drain Plug and empty the water reservoir. Collapse and remove the Telescopic Pole & Steam Nozzle.



## REMOVING MINERAL BUILD-UP

### STEP 1

Turn off and unplug the unit and cool for at least 30mins. Remove water tank. Mix water & vinegar solution and pour into water reservoir.







### STEP 2




Wait for 40mins, unscrew the Drain Plug and drain the water reservoir. Pour clean water into reservoir and let it drain. After the reservoir is empty, replace and tighten the Drain Plug.











## ACCESSORIES ASSEMBLY AND USE



## How to Steam



# TROUBLE SHOOTING

| Problems  | Reason   | Solution  |
|---|--|---|
| <p>Unit fails to steam.<br/>Indicating lamp does not illuminate</p>  | <p>The unit is not plugged in</p>  <p>House hold power system problem /fuse is blown.</p> | <p>Plug in the unit</p>  <p>Call a qualified electrician for help.</p>   |
| <p>Unit fails to steam<br/>Indicating lamp illuminates</p>           | <p>Mineral build-up</p>  <p>Water Tank is empty</p>                                       | <p>Follow the removal mineral build-up procedure.</p>  <p>50% Vinegar + 50% Water</p> <p>Refill the Water Tank</p> |
| <p>Noise in Steam Hose. Steam hose stops spraying steam</p>         | <p>Water drops gather in the Steam Hose</p>    |  <p>Straighten the Steam Hose.</p>  |
| <p>Steam is intermittent</p>                                       | <p>Mineral build-up in WaterTank</p>    | <p>Follow the removal mineral build-up procedure</p>  <p>50% Vinegar + 50% Water</p>                             |

Visit our website to find product tips, customer support and learn about  
SALAV patented steam technology.  
[www.salavusa.com](http://www.salavusa.com)

